


Montageanleitung DE

Installation instructions EN




Instructions de montage FR





Istruzioni di montaggio IT




Montage-instructie NL







# Subway Infinity




































Villeroy & Boch AG  
Saaruferstraße  
66693 Mettlach Deutschland  
Telefon: +49 (0) 68 64 / 8 10  
E-Mail: [information@villeroy-boch.com](mailto:information@villeroy-boch.com)  
[www.villeroy-boch.com](http://www.villeroy-boch.com)